


1. Protect your work surface - we advise using plastic sheeting or silicone mats.



2. Lay out materials.
3. Combine MakerPoxy Epoxy Resin and Hardener at a 1 to 1 ratio.
 - a. Combine enough to make a few colors to use in your molds.
 - b. We recommend starting with 1-2 oz. of each part for a combined 2-4 oz. total.
 - c. Stir very well for at least 3 minutes. Stir slowly to avoid bubbles, scraping sides of the cup.



4. Divide clear epoxy into the smaller cups to add pigments.
5. Mix in the desired amount of pigment. Start with a small amount - add more as needed until you get the color you want.



6. Pour colored pigments into molds.
7. Allow epoxy to cure in the molds for at least 24 hours before demolding.



8. Remove from molds and sand any sharp edges.

You Will Also Need (not included):

Work surface protection

Heat gun, gloves

Helpful Tips:

Warm your room, your resin, and your mold to at least 65°F. Cold resin or mold = bubbles in your epoxy.

Wear PPE as recommended in the MakerPoxy Safety Data Sheet (SDS).

You can try brushing the mica powder pigment into the mold before pouring epoxy, for a cool effect.